

Section: PARK PRO 16 HAND CONTROLS

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|---------------------|-----|---------------------|-----|
| 6216 | | | | | | |
| 1 | 1 | 1134-4156-01 | Panel bracket-inner | | | |
| 2 | 2 | 9897-0820-16 | Screw | | | |
| 3 | 2 | 9739-0831-22 | Nut | | | |
| 5 | 1 | 1134-4065-01 | Control shaft | | | |
| 6 | 1 | 1134-4079-01 | Spring | | | |
| 7 | 1 | 1134-4080-03 | Control sleeve | | | |
| 8 | 2 | 9959-0820-16 | Screw | | | |
| 9 | 1 | 1134-4077-01 | Throttle control | | | |
| 10 | 1 | 1134-4078-01 | Knob | | | |
| 11 | 1 | 1134-0240-00 | Shoulder screw | | | |
| 12 | 2 | 1134-4242-01 | Spacer washer | | | |
| 13 | 1 | 9694-0001-00 | Washer | | | |
| 14 | 1 | 9739-0831-22 | Nut | | | |
| 15 | 1 | 1134-4195-01 | Throttle cable | | | |
| 16 | 1 | 1134-3240-01 | Wire clamp | | | |
| 17 | 1 | 9943-0516-16 | Screw | | | |
| 18 | 1 | 1134-4072-01 | Control lever | | | |
| 19 | 1 | 1134-2551-01 | Knob | | | |
| 20 | 1 | 1134-3573-03 | PTO cable | | | |
| 21 | 1 | 1134-4217-01 | Switch bracket | | | |
| 22 | 2 | 9893-0616-16 | Screw | | | |
| 23 | 1 | 9400-0285-01 | Switch | | | |
| 24 | 2 | 9840-7716-16 | Screw | | | |
| 25 | 1 | 1134-4066-01 | Panel bracket-front | | | |
| 26 | 2 | 9893-0616-16 | Screw | | | |
| 27 | 1 | 1134-3986-01 | Front plate | | | |
| 28 | 4 | 9893-0616-16 | Screw | | | |
| 29 | 1 | 1134-4069-01 | Control lever | | | |
| 30 | 1 | 1134-2551-01 | Knob | | | |
| 31 | 1 | 1134-4073-01 | Cable holder | | | |
| 32 | 1 | 9942-0612-16 | Screw | | | |
| 33 | 1 | 1134-4006-01 | Cable | | | |
| 34 | 2 | 1134-2871-03 | Relay | | | |
| 35 | 3 | 9997-0520-16 | Screw | | | |
| 36 | 3 | 9739-0531-22 | Nut | | | |
| 37 | 1 | 1134-3981-03 | Dashboard | | | |
| 38 | 4 | 9946-0525-16 | Screw | | | |
| 39 | 1 | 1134-4154-01 | Cover | | | |
| 40 | 4 | 1134-4129-01 | Cover | | | |
| 41 | 1 | 1134-4093-01 | Ignition switch | | | |
| 42 | 1 | 1134-4097-01 | Cap | | | |
| 43 | 2 | 1134-4096-01 | Ignition key | | | |
| 44 | 1 | 1134-4095-01 | Nut | | | |
| 45 | 1 | 1134-2872-02 | Choke control | | | |
| 45A | 1 | 1134-4338-01 | .Control knob | | | |
| 46 | 2 | 9699-0028-02 | Flat washer | | | |
| 47 | 2 | 9400-0282-01 | Switch w.diode | | | |
| 48 | 1 | 9400-0280-02 | Cover-cruise contro | | | |
| 49 | 1 | 9400-0280-03 | Cover-height adjust | | | |
| 50 | 1 | 1134-4179-01 | Hour meter | | | |
| 51 | 1 | 1134-2871-01 | Relay | | | |
| 56 | 1 | 9699-0025-02 | Washer | | | |
| 99 | 1 | 9400-0290-01 | Tool for cover | | Tillbehör/Accessory | |