



Section: VILLA MASTER-SENATOR TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2721					
	2722					
4	1	1134-4613-01	Belt guide			
5	1	9699-0056-02	Flat washer			
6	1	1134-4519-01	Tension arm			
7	1	1134-3053-01	Tension roller			
8	1	1134-4614-01	Shoulder spacer			
9	1	9997-1040-16	Screw			
10	1	9699-0035-02	Flat washer			
11	1	9739-1031-22	Nut			
12	1	1134-9027-01	Tension roller			
13	1	1134-1795-01	Belt stirrup			
14	1	9997-1040-16	Screw			
15	1	9699-0035-02	Flat washer			
16	1	9739-1031-22	Nut			
17	1	1134-9065-01	Drive belt		= 9585-0124-01	
18	1	1134-1565-08	Spacer			
19	1	9997-0870-16	Screw			
20	2	9699-0056-02	Flat washer			
21	1	9739-0831-22	Nut			
22	1	1134-3212-01	Spring			
23	1	1134-3716-03	Transaxle		Peerless MST 205	
24	4	9997-0870-16	Screw			
25	4	9747-0831-02	Lock nut			
26	1	1134-4687-01	Strut			
27	2	9945-0816-16	Screw			
28	1	1134-1849-01	Belt pulley			
29	1	9600-0050-00	Key			
30	1	9650-0016-04	Lock ring			
31	1	1134-4707-01	Belt guide			

TEST