



## Section: HERKULES MB 432 HANDLEBAR FRONT WHEELS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1588					
1	1	1111-2805-03	Front axle			
2	2	1111-1504-01	Retainer			
3	2	9947-0616-16	Screw			
4	1	1111-2818-02	Height adjusting ro			
5	2	9675-0011-00	Starlock			
6	1	1111-2819-01	Spring			
10	2	1111-1138-01	Spring			
11	2	1111-0817-03	Wheel w/o bearing			
12	4	9549-0015-00	Ball bearing			
13	2	1111-0466-00	Seal grease			
15	2	9699-0100-02	Washer			
16	2	9943-0612-16	Screw			
17	2	1111-1506-01	Hub cap			
20	2	1111-3021-01	Handlebar attachmen			
21	4	9795-3531-02	Nut			
22	1	1111-3113-01	Handlebar-lower par			
23	4	1111-3023-01	Locking knob			
24	2	9899-3557-12	Screw		L = 57 mm	
25	2	9899-3545-12	Screw		L = 45 mm	
26	6	9699-0028-02	Flat washer			
27	2	9939-0820-16	Screw			
27A	1	9900-0060-00	Allen wrench		Ej ill/not ill.	
28	2	1111-3024-01	Attachment plate			
33	2	1111-0178-00	Reinforcement			
43	1	1111-3112-01	Handlebar-upper par			
44	1	1111-3062-01	Eyelink			
45	1	1111-3351-01	Throttle control			
47	1	9948-0660-16	Screw		L = 60 mm	
48	1	9747-0631-02	Lock nut			
52	1	1111-2953-01	Control handle			
53	1	1111-2968-01	Engine brake cable			
54	1	1111-2969-01	Cable attachment			
56	2	1111-2018-01	Cable holder			
57	2	9836-9216-12	Screw			
63	1	1111-2927-01	Battery holder			