



Section: HERKULES MB 432 REAR WHEELS

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	1588					
1	1	1111-3114-01	Rear axle			
2	2	1111-2814-01	Bushing			
3	4	9947-0616-16	Screw			
4	5	9838-9522-12	Screw			
5	1	1111-2798-01	Height adj.quadrant			
6	1	1111-2816-01	Height adj.lever			
7	1	1111-2817-01	Lever knob			
8	2	9943-0612-16	Screw			
10	2	1111-0817-04	Wheel w/o bearing			
11	4	9549-0015-00	Ball bearing			
12	2	1111-0466-00	Seal grease			
14	2	1111-2423-01	Spacer			
15	2	9699-0100-02	Washer			
16	2	9943-0620-16	Screw			
17	2	1111-1506-01	Hub cap			
20	2	1111-3060-01	Spring			
51	1	1111-2924-02	Axle			
52	2	9675-0017-02	Lock washer			
53	1	1111-3102-04	Cover-red			

test