



Section: JP47 B4Z (XTE50)

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|---------------------|-----|--------------|-----|
| | 504 | | | | | |
| | 623 | | | | | |
| 1 | 1 | 1117-3263-08 | Deck-green | | | |
| 2 | 1 | 1117-1173-01 | Shaft-backside | | | |
| 3 | 2 | 9595-0212-00 | Locating pin | | | |
| 4 | 2 | 1117-3256-01 | Wheel protection ca | | | |
| 5 | 2 | 1117-1174-01 | Height adjust lever | | | |
| 6 | 2 | 1111-2665-01 | Wheel assy | | Inkl. pos 74 | |
| 7 | 4 | 9694-0003-00 | Washer | | | |
| 8 | 1 | 1117-3008-01 | Baffle-rear | | | |
| 9 | 14 | 9836-9516-12 | Screw | | | |
| 10 | 1 | 1117-1156-05 | Rear flap-green | | | |
| 11 | 1 | 1117-1143-01 | Shaft | | | |
| 12 | 1 | 1117-1126-01 | Spring-rear flap | | | |
| 13 | 1 | 1117-1155-05 | Flap holder-green | | | |
| 14 | 1 | 1117-3007-01 | Baffle-front | | | |
| 15 | 2 | 9699-0078-02 | Washer | | | |
| 16 | 2 | 9898-0845-12 | Screw | | | |
| 17 | 1 | 1117-1334-01 | Front shaft | | | |
| 18 | 2 | 9716-0831-02 | Nut | | | |
| 19 | 1 | 1117-1130-01 | Connection rod | | | |
| 20 | 2 | 1111-3163-01 | Wheel | | | |
| 21 | 2 | 1111-2804-01 | Hub cap-yellow | | | |
| 22 | 2 | 1111-2815-01 | Hub cap-yellow | | | |
| 23 | 6 | 1117-1131-01 | Nut | | | |
| 24 | 1 | 9865-0616-16 | Screw | | | |
| 25 | 4 | 1117-1364-01 | Screw | | | |
| 26 | 1 | 1117-3237-01 | Assy. kit | | | |
| 27 | 1 | 1117-1355-01 | Socket wrench | | | |
| 28 | 6 | 9699-0028-02 | Flat washer | | | |
| 29 | 4 | 9579-0008-00 | Cable holder | | | |
| 30 | 2 | 1117-3194-01 | Locking knob | | | |
| 31 | 6 | 9799-0831-02 | Nut | | | |
| 32 | 1 | 9799-0631-02 | Nut | | | |
| 33 | 1 | 1117-1149-01 | Handle-lower part | | | |
| 34 | 4 | 9699-0024-02 | Flat washer | | | |
| 35 | 1 | 1117-3221-01 | OPC lever | | | |
| 36 | 1 | 1117-3090-02 | Dashboard-green | | | |
| 37 | 1 | 1117-1157-05 | Grassbag cover-gree | | Inkl. pos 68 | |
| 38 | 1 | 1117-1218-01 | Lower grass bag | | | |
| 39 | 1 | 9997-0830-16 | Screw | | 30 mm | |
| 40 | 1 | 1117-3035-01 | Handlebar-upper | | | |
| 41 | 3 | 9678-0009-02 | Lock washer | | | |
| 42 | 1 | 9600-0014-00 | Key | | | |
| 43 | 1 | 1117-1387-01 | Blade holder | | | |
| 44 | 1 | 1117-3015-01 | Blade | | | |
| 45 | 1 | 1117-3105-01 | Throttle control | | | |
| 46 | 1 | 1117-1065-01 | Spring washer | | | |
| 47 | 1 | 9987-5251-12 | Screw | | | |
| 48 | 2 | 9997-0614-16 | Screw | | | |
| 49 | 2 | 1117-1175-01 | Washer | | | |
| 50 | 1 | 1117-1120-01 | Spring | | | |
| 51 | 2 | 9591-0011-00 | Pin | | | |
| 52 | 2 | 1117-1083-01 | Safety ring | | | |
| 53 | 4 | 1111-2830-01 | Support washer | | | |
| 54 | 2 | 1111-3075-01 | Pinion-plastic whee | | | |
| 55 | 1 | 1117-1190-01 | Clutch cable | | Inkl. pos 72 | |
| 56 | 2 | 9865-0816-16 | Screw | | | |
| 57 | 2 | 1117-1161-01 | Wheel protection | | | |
| 58 | 4 | 9799-0531-02 | Nut | | | |
| 59 | 1 | 1117-3017-01 | V-belt | | | |
| 60 | 1 | 9997-0840-16 | Screw | | M8 x 40 | |
| 61 | 2 | 9699-0062-02 | Flat washer | | | |
| 62 | 1 | 1117-1147-01 | Transmission cap | | | |
| 63 | 3 | 9997-0545-12 | Screw | | | |
| 64 | 1 | 1117-3121-01 | Screw | | | |
| 65 | 1 | 1111-2927-01 | Battery holder | | | |
| 66 | 2 | 9549-0053-00 | Ball bearing | | | |

Section: JP47 B4Z (XTE50)

| Pos. | Quantity | Spare part No | Description | Kit | Notes | New |
|------|----------|---------------|--------------------|-----|------------------|-----|
| | 504 | | | | | |
| | 623 | | | | | |
| 67 | 2 | 1111-3256-01 | Drive key | | | |
| 68 | 1 | 1117-1135-02 | .Cover-black | | | |
| 69 | 1 | 1117-3018-01 | .Pulley | | | |
| 70 | 1 | 1111-2382-01 | .Pin | | | |
| 71 | 1 | 1117-3016-01 | Gear box assy | | Inkl. pos 69, 70 | |
| 72 | 1 | 1134-3203-04 | .Cable protector | | | |
| 73 | 1 | 1117-1183-01 | Engine brake cable | | | |
| 74 | 2 | 1111-9047-01 | .Ball bearing kit | | | |
| 75 | 1 | 1117-1116-01 | Rope holder | | | |
| 76 | 1 | 1117-1258-01 | Knob | | | |
| 77 | 2 | 1111-3164-01 | Wheel axle bolt | | | |
| 78 | 1 | 1117-1179-01 | Bolt | | | |
| 79 | 2 | 9836-9512-12 | Screw | | | |
| 80 | 4 | 9549-0053-00 | Ball bearing | | | |
| 81 | 1 | 1117-1374-01 | Control handle | | | |
| 82 | 1 | 1117-1114-01 | Support | | | |
| 83 | 1 | 1117-3001-01 | Mulch plug | | | |
| 84 | 1 | 9595-0258-00 | Locating pin | | | |

test