



## Section: SWEEPER ART.NO 13-0920-11 TRANSMISSION

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
		0920				
2	1	1134-2762-01	Case			
4	1	1134-2763-01	Transmission cover			
6	1	9500-9982-00	Oil plug			
7	2	9591-0020-00	Pin			
8	9	9997-0635-12	Screw		L = 35 mm	
10	14	9739-0631-22	Nut			
11	5	9997-0670-12	Screw		L = 70 mm	
12	1	1134-2584-01	Sprocket			
13	1	9907-1020-19	Set screw			
14	1	9695-0006-00	Washer			
16	2	9549-0045-00	Ball bearing			
17	2	9404-0074-00	Seal ring			
18	1	1134-2585-01	Output shaft			
21	1	1134-2674-01	Sprocket assy		Inkl. 22-30, 39-40	
22	1	1134-2587-01	.Sprocket			
23	1	1134-2588-01	.Shaft			
25	1	9600-0148-00	.Flat key			
26	1	9650-0017-04	.Retaining ring			
27	2	9695-0005-00	.Washer			
30	2	9549-0017-00	.Ball bearing			
31	1	9589-0013-00	Chain			
32	1	1134-2589-01	Chain tensioner			
33	1	1134-2590-01	Compression spring			
34	1	1111-1706-01	Clamp			
35	1	9943-0510-16	Screw			
39	2	9549-0019-00	.Ball bearing			
40	3	9695-0005-00	.Washer			
42	1	9651-0040-04	Retaining ring			
43	1	1134-2757-01	Drive sheave			
44	1	9600-0145-00	Flat key			
45	1	9699-0056-02	Flat washer			
47	1	9958-0820-16	Screw			
65	1	1134-9014-01	V-belt		= 9585-0058-00	
68	2	1134-2796-01	Screw		L = 270 mm	
72	2	9591-0031-00	Pin			
75	20	1134-3880-01	Brush			
76	2	1134-3884-01	Brush			
78	2	1134-2798-01	Carrier			
79	2	1134-2619-01	Washer			
82	2	1134-2620-01	Washer			
83	8	9942-0825-16	Screw			
84	8	9632-0509-00	Pop rivet			
85	1	9404-0073-00	Seal ring			
92	1	1134-1322-01	Spring			
93	1	1134-3043-01	Tension roller			