



## Section: ESTATE PRESIDENT ESTATE TORNADO HST BRAKE CONTROL DRIVE CON

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
	2522					
	2532					
1	1	1136-0510-01	Pedal			
2	1	1136-0151-01	Pedal cover			
3	1	1136-0254-01	Clamp			
4	4	9847-8016-16	Screw			
5	1	1136-0117-01	Brake rod			
6	1	9699-0090-02	Flat washer			
7	1	9675-0012-02	Locking washer			
8	1	1136-0248-01	Pivot bolt			
9	1	1136-0218-01	Spring			
10	2	9699-0035-02	Flat washer			
11	1	1136-0329-01	Clamp			
12	1	9799-1031-02	Nut			
13	1	9747-1031-02	Lock nut			
14	1	9699-0090-02	Flat washer			
15	1	9747-0831-02	Lock nut			
31	1	1136-0441-01	Axle			
32	1	1136-0217-01	Spring			
33	2	1136-0256-01	Plate			
34	4	9847-8016-16	Screw			
35	1	1136-0119-01	P-brake lever			
36	1	9675-0011-00	Starlock			
37	1	1136-0392-01	Knob			
51	1	1136-0507-01	Drive pedal			
52	1	1136-0149-01	Pedal cover-front			
53	1	1136-0150-01	Pedal cover-rear			
54	1	1136-0538-01	Support			
55	2	1136-0121-01	Bushing			
56	1	9501-0500-00	Grease joint			
57	2	9997-0616-16	Screw			
58	2	9739-0631-22	Nut			
59	1	1136-0500-01	Pedal axle			
60	2	9650-0020-04	Circlip			
61	1	1136-0090-01	Washer			
62	1	9997-0816-16	Screw			
63	1	9683-0030-02	Lock washer			
64	1	1136-0118-01	Drive rod			
65	1	1136-0241-01	Pivot bolt			
66	1	1136-0247-01	Pivot bolt			
67	2	9799-0831-02	Nut			
68	2	9747-0831-02	Lock nut			
69	1	9699-0035-02	Flat washer			
70	1	9699-0028-02	Flat washer			
71	1	9747-0631-02	Lock nut			
72	1	1136-0533-01	Support			
73	1	9699-0060-02	Flat washer			
74	1	9747-0631-02	Lock nut			
75	1	9997-0620-16	Screw			
76	1	9747-0631-02	Lock nut			
77	1	1136-0330-01	Clamp			
78	2	9848-8013-16	Screw			
80	1	1136-0407-01	Plate			
81	2	9948-0320-16	Screw			
82	2	9683-0005-02	Lock washer			
83	2	9799-0331-02	Nut			