



## Section: KANZAKI TRANSAXLE K46F-K46S BRAKE

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

K46F K46S

2	1	1	1139-1260-01	Brake shoe		
3	1	1	1139-1261-01	Brake arm		
4	1	1	1139-1320-01	Brake shaft		
5	1	1	1139-1263-01	Return spring		
6	1	1	1139-1264-01	Brake actuator		
7	1	1	1139-1282-01	Pin		
8	2	2	1139-1114-01	O-ring		
9	2	2	1139-1281-01	Pin		

test