



M040

## Section: KANZAKI TRANSAXLE K46 CONTROL SHAFT

Pos.	Quantity	Spare part No	Description	Kit	Notes	New
------	----------	---------------	-------------	-----	-------	-----

K46F K46S

1	1	1	1139-1315-01	Control shaft		
2	1	1	1139-1316-01	Fulcrum		
3	1	1	1139-1312-01	Spring		
4	1	1	1139-1314-01	Control arm		
5	1	1	1139-1313-01	Control lever		
6	1	1	1139-1250-01	Jerky plate		
7	1	1	1139-1102-01	Washer		
8	1	1	1139-1327-01	Pin		
9	1	1	1139-1329-01	Pin		
10	1	1	1139-1285-01	Pin		
11	2	2	1139-1115-01	O-ring		
12	1	1	1139-1127-01	Nut		

test