



Genuine Spare Parts



Joist
Spareparts
Joist



Utgåva Issue		Bildnr Picture No		SPR 270- SPR 270C CHASSI		SPR 270- SPR 270C CHASSIS		Sida Page	
2006-12		2158						346	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4122 -11	4123 -11							
X	1	1	1	1911-4518-01	Start kpl.....	Starter assy.....		Inkl. pos 2 - 7	
X	2	1	1	1911-4467-01	• Startsnöre.....	• Starter cord.....			
X	3	1	1	1911-3479-01	• Starthandtag.....	• Starter handle.....			
X	4	1	1	1911-4472-01	• Returfjäder.....	• Rewind spring.....			
X	5	1	1	1911-4481-01	• Lihjul.....	• Starter pulley.....			
X	6	1	1	1911-4484-01	• Bricka.....	• Washer.....			
X	7	1	1	1911-4497-01	• Skruv.....	• Screw.....			
X	8	1	1	1911-4459-01	Luftledare.....	Air conveyor.....			
X	9	1	1	1911-4495-01	Skruv.....	Screw.....			
X	10	1	1	1911-4468-01	Gummihylsa.....	Rubber grommet.....			
X	11	1	1	6995240	Handtag kpl.....	Handle assy.....	Inkl. pos 12 - 14		
X	12	1	1	6995114	• Fjäder.....	• Spring.....			
X	13	1	1	6995134	• Gasreglage.....	• Throttle lever.....			
X	14	1	1	6995016	• Spännstift.....	• Spring pin.....			
X	15	1	1	6995196	Lock.....	Cap.....			
X	16	1	1	1911-4469-01	Dämpement.....	Shock absorber.....			
X	17	1	1	1911-4494-01	Skruv.....	Screw.....			
X	18	2	2	1911-4489-01	Lock.....	Cap.....			
X	19	1	1	6995226	Brytare.....	Switch.....			
X	20	1	1	6995198	Rör.....	Tube.....			
X	21	2	2	6995199	Röranslutning.....	Tube connection.....			
X	22	2	2	6995197	Rör.....	Tube.....			
X	23	1	1	6995218	Kåpa- bakre.....	Cover- rear.....			
X	24	1	1	6995215	Gasreglagelänk.....	Throttle rod.....			
X	25	1	1	6995135	Säkerhetsspärr.....	Safety lever.....			
X	26	1	1	6995195	Handtag- överdel.....	Handle- upper.....			
X	27	5	5	1911-4495-01	Skruv.....	Screw.....			
X	32	1	1	1911-4494-01	Skruv.....	Screw.....			
X	33	1	1	1911-4469-01	Dämpement.....	Shock absorber.....			
X	34	1	1	1911-4458-01	Handtag.....	Handle.....			
X	35	3	3	1911-4497-01	Skruv.....	Screw.....			
X	36	1	1	1911-4466-01	Plåt.....	Plate.....			
X	41	4	4	1911-4496-01	Skruv.....	Screw.....			
X	42	1	1	1911-4470-01	Svärdplåt.....	Bar plate.....			
X	43	1	1	1911-4491-01	Kedjespännarmutter.....	Chain tensioner nut.....			
X	44	1	1	1911-4492-01	Kedjespännarskruv.....	Chain tensioner screw.....			
X	45	1	1	1911-4479-01	Bult.....	Pin.....			
X	46	1	1	1911-4477-01	Bromsband.....	Brake band.....			
X	47	1	1	1911-4487-01	Pinne.....	Pin.....			
X	48	1	1	1911-4476-01	Fjäder.....	Spring.....			
X	49	1	1	1911-4471-01	Arm.....	Lever.....			
X	50	1	1	1911-4475-01	Fjäder.....	Spring.....			
X	51	1	1	1911-4461-01	Mutter.....	Nut.....			
X	52	1	1	1911-4485-01	Bricka.....	Washer.....			
X	53	1	1	1911-4444-01	Bussning.....	Bushing.....			
X	54	1	1	1911-4478-01	Handskydd.....	Hand guard.....			
X	55	1	1	1911-4474-01	Fjäder.....	Spring.....			
X	56	1	1	1911-4520-01	Kedjebromsarm.....	Chain brake lever.....			
X	57	1	1	1911-4486-01	Stift.....	Pin.....			
X	58	1	1	1911-4445-01	Bussning.....	Bushing.....			
X	59	1	1	1911-4473-01	Fjäder.....	Spring.....			
X	60	1	1	1911-4454-01	Motvikt.....	Counter weight.....			
X	61	1	1	1911-4493-01	Skruv.....	Screw.....			
X	63	1	1	1911-4460-01	Bromskåpa.....	Brake cover.....			
X	64	1	1	1911-4451-01	Kopplingshus- gul.....	Clutch housing- yellow.....			
X	65	1	1	1911-4527-01	Bussning.....	Bushing.....			
X	66	1	1	1911-3030-01	Mutter.....	Nut.....			
X	71	1	1	1911-4498-01	Svärd.....	Bar.....	10" (3/8" x 0.050)		
X	71	1	1	1911-4499-01	Svärd.....	Bar.....	10" (1/4" x 0.050)		
X	72	1	1	1911-4500-01	Kedja (40E).....	Chain (40E).....	91VG (3/8")		
X	72	1	1	1911-4501-01	Kedja (60E).....	Chain (60E).....	25AP (1/4")		
X	73	1	1	1911-4455-01	Kedjeskydd.....	Chain cover.....			



Utgåva Issue		Bildnr Picture No		SPR 270- SPR 270C MOTOR		SPR 270- SPR 270C ENGINE		Sida Page	
2006- 12		2159						348	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4122 -11	4123 -11							
X	1	1	1	6995173	Mutter.....	Nut.....			
X	2	1	1	6995207	Svånghjul.....	Flywheel.....		Inkl. pos 3 - 6	
X	3	2	2	6995224	• Skruv.....	• Screw.....			
X	4	2	2	6995208	• Startspärr.....	• Starter hook.....			
X	5	2	2	6995250	• Fjäder.....	• Spring.....			
X	6	2	2	6995225	• Bricka.....	• Washer.....			
X	7	1	1	6995247	Tätningarring.....	Seal ring.....			
X	8	2	2	6995170	Kullager.....	Ball bearing.....			
X	9	1	1	6995018	Kil.....	Key.....			
X	10	1	1	6995202	Vevaxel.....	Crankshaft.....			
X	11	2	2	6995169	Bricka.....	Washer.....			
X	12	1	1	6995237	Nållager.....	Needle bearing.....			
X	13	1	1	6995200	Kolv.....	Piston.....			
X	14	1	1	6995172	Kolvbult.....	Piston pin.....			
X	15	2	2	6995171	Låsring.....	Circlip.....			
X	16	1	1	6995201	Kolvring.....	Piston ring.....			
X	17	1	1	6995245	Cylinder.....	Cylinder.....			
X	18	1	1	6995186	Stabilisator.....	Stabilizer.....			
X	19	4	4	6995252	Skruv.....	Screw.....			
X	20	1	1	6995248	Tätningarring.....	Seal ring.....			
X	21	4	4	6995229	Skruv.....	Screw.....			
X	22	1	1	6995185	Packning.....	Gasket.....			
X	23	1	1	6995246	Ljuddämpare.....	Muffler.....			
X	24	1	1	6995251	Plåt.....	Plate.....			
X	25	2	2	6995182	Skruv.....	Screw.....			
X	26	1	1	6995210	Jordkabel.....	Earth cable.....			
X	27	1	1	6995227	Stoppkabel.....	Stop cable.....			
X	28	2	2	6995234	Skruv.....	Screw.....			
X	29	1	1	6995209	Elektronikspole.....	Electronic coil.....		Inkl. pos 30 - 31	
X	30	1	1	6995022	• Tändstiftsfjäder.....	• Spark plug spring.....			
X	31	1	1	6995066	• Tändstiftshatt.....	• Spark plug cover.....			
X	32	2	2	6995238	Distans.....	Spacer.....			
X	33	1	1	9400- 0258- 00	Tändstift.....	Spark plug.....		Champion CJ7Y	
X	34	1	1	6995183	Insugningsrör.....	Intake manifold.....			
X	35	2	2	6995167	Skruv.....	Screw.....			
X	36	1	1	6995212	Tätning.....	Seal.....			
X	37	1	1	6995244	Förgasare kpl.....	Carburettor assy.....			
X	38	1	1	6995214	Gummihylsa.....	Rubber grommet.....			
X	39	1	1	6995213	Chokearm.....	Choke rod.....			
X	40	1	1	6995243	Luftfilterhus.....	Air cleaner base.....			
X	41	1	1	6995211	Platta.....	Plate.....			
X	42	2	2	6995168	Skruv.....	Screw.....			
X	43	1	1	6995217	Luftfilter.....	Air filter.....			
X	44	1	1	6995216	Luftfilterlock.....	Air cleaner cover.....			
X	51	2	2	1911- 4495- 01	Skruv.....	Screw.....			
X	52	1	1	6995175	Kåpa- främre.....	Cover- front.....			
X	53	1	1	6995239	Vevhus.....	Crankcase.....			
X	54	2	2	6995187	Skruv.....	Screw.....			
X	55	1	1	6995221	Vevhusventil.....	Breather valve.....			
X	56	1	1	6995232	Gummihylsa.....	Rubber grommet.....			
X	57	2	2	6995193	Lock.....	Cap.....			
X	58	1	1	6995228	Primer.....	Air purge primer.....			
X	59	1	1	6995188	Gummihylsa kpl.....	Rubber grommet assy.....		Inkl. pos 60 - 61	
X	60	1	1	6995189	• Gummihylsa.....	• Rubber grommet.....			
X	61	1	1	6995174	• Bränslefilter.....	• Fuel pick- up.....			
X	62	1	1	6995190	Bränsleledning.....	Fuel hose.....			
X	63	2	2	1911- 4495- 01	Skruv.....	Screw.....			
X	64	1	1	6995249	Kåpa- övre.....	Cover- upper.....			
X	65	1	1	6995194	Skydd.....	Guard.....			
X	66	1	1	6995180	Kedjestopp.....	Chain stop.....			
X	67	1	1	6995179	Skruv.....	Screw.....			
X	71	1	1	6995204	Packning.....	Gasket.....			
X	72	1	1	6995223	Bricka.....	Washer.....			

