


Genuine Spare Parts

SP 422








SP 422 - Model Year 2008

Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	1	123120004/0	Mutter	Nut	
2	1	383880002/0	Svånghjul	Flywheel Assy	
3	1	6995281	Vevhus	Crankcase Ass.Y	
4	1	6995278	Tätningring	Seal Ring	
5	2	6995277	Kullager	Bearing	
6	1	6995283	Packning	Gasket Set	KIT POS. 100
7	1	6995255	Låsring	Elastic Ring	
8	1	6995257	Tätningring	Seal Ring	
9	2	6995028	Styrpinne	Pin	
10	4	6995276	Skruv	Screw	
11	1	6995314	Vevaxel	Crankshaft	
12	2	6995265	Bricka	Washer	
13	1	6995304	Lager	Bearing	
14	2	6995256	Låsring	Washer, Piston Pin	
15	1	6995313	Kolvbult	Piston Pin	
16	1	6995287	Kolv	Piston	
17	2	6995258	Kolvring	Piston Ring	
18	1	6995283	Packning	Gasket Set	KIT POS. 100
19	1	6995284	Cylinder	Cylinder Assy	
20	6	123878020/0	Skruv	Screw	
21	1	6995320	Lock	Cover	
22	2	6995322	Packning	Gasket	
23	1	6995321	Lock	Cover	
24	1	23051000/0	Tändstift	Spark Plug	
25	4	6995319	Skruv	Screw	
26	2	123878021/0	Skruv	Screw	
27	1	383044000/0	Elektronikspole	Electronic Coil	
30	2	123878028/0	Skruv	Screw	
31	1	123280012/0	Packning	Gasket	
32	1	183740000/0	Ljuddämpare	Muffler Assy	
33	1	323140055/0	Deflektor	Deflector	
34	1	123878022/0	Skruv	Screw	
35	2	2432040	Mutter	Nut	
41	1	123280015/0	Packning	Gasket	
43	1	383073500/0	Insugningsrör	Intake Manifold	
44	1	123280011/0	Packning	Gasket	
45	1	123054015/0	Förgasare	Carburettor	
45	1	123054016/0	Förgasare	Carburettor	
46	1	123878024/0	Skruv	Screw	
47	1	323073503/0	Luftintag	Air Manifold	
48	2	123878019/0	Skruv	Screw	
49	1	323275015/0	Packning	Gasket	
50	1	383215001/0	Koppling kpl	Clutch Ass.Y	
51	1	123430566/0	Fjäder	Spring	
52	1	323657006/0	Bricka	Sprocket Washer	
53	1	323050003/0	Kopplingshjul	Drum Ass'Y, Clutch	
54	1	123235000/0	Nållager	Needle Bearing	
55	1	383594502/0	Oljepump	Oil Pump Assy	
55	1	383594503/0	Oljepump	Oil Pump Assy	
56	1	323878026/0	Skruv	Female Screw	
57	4	123878021/0	Skruv	Screw	
58	1	323109524/0	Lock	Cover Pump	
60	1	323867005/0	Rör	Tube	
61	1	323867004/0	Oljeslang	Pickup Oil	
62	1	323220002/0	Oljefilter	Oil Filter Ass.Y	
63	1	323652503/0	Bricka	Washer	
71	4	123878022/0	Skruv	Screw	
72	1	123878024/0	Skruv	Screw	
73	1	323057003/0	Vevhus	Crankcase Ass.Y	
74	1	323790010/0	Lock	Cap	
75	2	123878024/0	Skruv	Screw	
76	1	323275008/0	Vibrationsdämpare	Shock Absorber	
77	1	323275009/0	Vibrationsdämpare	Shock Absorber	
78	1	323790011/0	Lock	Cap	
81	1	323202000/0	Kedjeskydd	Chain Guard	
82	1	123878018/0	Skruv	Screw	
83	1	123878020/0	Skruv	Screw	
84	1	323311005/0	Platta	Plate	
100	1	6995283	Packning	Gasket Set	





SP 422 - Model Year 2008

Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	3	123878024/0	Skruv	Screw	
2	1	383058018/0	Start kpl-gul	Starter Assy Yellow	
3	1	323044211/0	Hylsa	Grommet	
4	1	323300004/0	Starthandtag	Starter Handle	
5	1	123234002/0	Startsnöre	Starter Cord	
6	1	123430577/0	Startfjäder	Starter Spring	
7	1	323604003/0	Linhjul	Starter Pulley	
8	1	3613420	Bricka	Washer	
9	1	123878024/0	Skruv	Screw	
10	1	323107503/0	Luftledare	Air Conveyer	
15	1	383300015/0	Handtag kpl	Handle Assy	
16	1	123430567/0	Fjäder	Spring	
17	1	323315063/0	Gasreglage	Throttle Lever	
21	1	123835001/0	Gasreglagelänk	Throttle Rod	
22	1	323315064/0	Säkerhetsspärr	Safety Lever	
23	1	323109520/0	Styre-överdel	Handle, Upper Part	
24	1	123878025/0	Skruv	Screw	
25	1	323790009/0	Lock	Cap	
26	1	383790003/0	Tanklock	Cap Oil Tank	
28	1	3210970	Brytare	Stop Switch	
29	1	123065018/0	Stoppkabel	Stop Wire	
30	1	123065017/0	Jordkabel	Earth Cable	
31	1	323275013/0	Hylsa	Grommet	
32	1	383790002/0	Tanklock	Fuel Tank-Cap Ass.Y	
33	1	323867003/0	Bränsleslang	Fuel Line	
34	1	183520000/0	Bränslefilter	Intake Filter Assy	
35	1	323275011/0	Hylsa	Grommet	
36	1	183875001/0	Ventil	Breather Valve Ass.Y	
38	1	123878024/0	Skruv	Screw	
39	1	123430568/0	Fjäder	Spring	
40	1	123878022/0	Skruv	Screw	
41	1	123878024/0	Skruv	Screw	
42	1	323208402/0	Platta	Plate	
43	1	123430569/0	Fjäder	Spring	
45	4	123878024/0	Skruv	Screw	
46	1	323087005/1	Cylinderkåpa	Cylinder Cover Yellow	
47	1	323653500/0	Lock	Cap	
49	1	323796006/0	Hylsa	Grommet	
50	1	323796007/0	Hylsa	Grommet	
51	1	323315065/0	Chokearm	Choke Lever	
52	1	383220000/0	Luftfilter	Air Filter	
53	1	323090019/0	Luftfilterkåpa-gul	Filter Cover Yellow	
54	1	383593501/0	Låsratt	Knob Ass`Y	
61	4	123878025/0	Skruv	Screw	
62	1	323105001/0	Handtag	Handle	
65	1	123900113/0	Svärd	Guide Bar 16"	16" 325" .050" (1.3 mm)
66	1	123920100/0	Kedja	"Chain 16""	16" 325" .050" (1.3 mm) - 66E
71	1	383059013/0	Kopplingshus kpl-gul	Clutch Ho. W/Br. Assy Yellow	
72	2	123878023/0	Skruv	Screw	
73	1	323109525/0	Bromskåpa	Brake Cover	
74	1	112154320/0	Mutter	Nut	
75	1	123657007/0	Bricka	Washer	
76	1	123430573/0	Fjäder	Spring	
77	1	123753001/0	Stift	Roller	
78	1	383315051/0	Bromsarm	Chain Brake Lever	
79	1	123044213/0	Bussning	Bushing	
80	1	123430572/0	Fjäder	Spring	
81	1	323080001/0	Balansvikt	Balance Weigth	
82	1	123044213/0	Bussning	Bushing	
83	1	123878017/0	Skruv	Screw	
84	1	323670001/0	Bricka	Plate	
85	1	123430573/0	Fjäder	Spring	
86	1	123430565/0	Fjäder	Spring	
87	1	323315067/0	Arm	Lever	
88	1	123753000/0	Stift	Needle	
89	1	323448003/0	Bromsband	Brake Band	
91	1	123878027/0	Skruv	Screw	
92	1	123510096/0	Kedjespännare	Bar Adjusting Block	
93	1	123796005/0	Bult	Pin	
94	1	323311006/0	Platta	Plate	
95	2	123878023/0	Skruv	Screw	
96	2	2670270	Mutter	Nut	
100	1	4181307	Kedjeskydd	Chain Cover	