

Genuine Spare Parts

www.stiga.com


SP 36 Model Year 2012

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

COPYRIGHT by GLOBAL GARDEN PRODUCTS


All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.








| Pos. Fig. | Antal Quantity | Art No Part No | Benämning | Description | Anmärkning Notes |
|-----------|----------------|----------------|---------------------------|---------------------------|------------------|
| 1 | 1 | 118800707/0 | Skruv | F. H. Screw | |
| 2 | 1 | 118800655/0 | O-ring | O-ring | |
| 3 | 1 | 118800717/0 | Dämpelement | Gear cover | |
| 4 | 1 | 118800708/0 | Skruv | Tornillo de tension | |
| 5 | 1 | 118800734/0 | Skruv | Tension carriage | |
| 6 | 1 | 118800629/0 | Skruv | Screw | |
| 7 | 1 | 118800718/0 | Stöd | Support | |
| 8 | 1 | 118800643/0 | Bricka | Washer | |
| 9 | 1 | 118800712/0 | Bucking spike | Bucking spike | |
| 10 | 2 | 118800633/0 | Skruv | Screw | |
| 11 | 2 | 118800635/0 | Skruv | Screw | |
| 12 | 1 | 118800730/0 | Chain guard | Chain guard | |
| 13 | 2 | 118800638/0 | Mutter | Nut | |
| 14 | 1 | 118800623/0 | Kettensteg 3/8" | Guide bar, 3/8" spez., | |
| 15 | 1 | 4113703 | Kedja | Chain 14" (35 cm) | |
| 16 | 1 | 118800728/0 | Handtag | Handle housing compl., | |
| 17 | 1 | 118800727/0 | Safety lever | Safety lever | |
| 18 | 1 | 118800726/0 | Gasreglage | Gas lever | |
| 19 | 1 | 118800666/0 | Fjäder | Spring | |
| 20 | 1 | 118800723/0 | Grip cup | Grip cup | |
| 21 | 1 | 118800713/0 | Rubber element | Rubber element | |
| 22 | 2 | 118800630/0 | Skruv | Screw | |
| 23 | 3 | 118800665/0 | Fjäder | Spring | |
| 24 | 6 | 2123100 | Skruv | Screw | |
| 25 | 1 | 118800735/0 | Handtagsgrepp | Handle bar | |
| 26 | 2 | 118800632/0 | Skruv | Screw | |
| 27 | 2 | 118800626/0 | Skruv | Screw | |
| 28 | 2 | 118800639/0 | Mutter | Nut | |
| 29 | 1 | 118800695/0 | Start kpl | Starter compl. | |
| 30 | 1 | 118800677/0 | Air guide | Air guide | |
| 31 | 1 | 118800657/0 | Starter rope | Starter rope | |
| 32 | 1 | 118800685/0 | Star handtag | Starter handle | |
| 33 | 2 | 118800632/0 | Skruv | Screw | |
| 34 | 1 | 118800631/0 | Skruv | Screw | |
| 35 | 1 | 118800729/0 | Hus | Main housing | |
| 36 | 4 | 118800645/0 | Spacer tube | Spacer tube | |
| 37 | 1 | 118800646/0 | Stift | Pin | |
| 38 | 1 | 118800715/0 | Fuel hose | Fuel hose | |
| 39 | 1 | 118800696/0 | Bränsleslang | Fuel pick-up | |
| 40 | 1 | 118800700/0 | Oljevol | Tank cap | |
| 41 | 1 | 118800656/0 | Packning | Gasket | |
| 42 | 1 | 118800697/0 | Oljevol | Oil tank cap | |
| 43 | 1 | 118800654/0 | O-ring | O-ring | |
| 44 | 1 | 118800699/0 | Ventilation hose compl. | Ventilation hose compl. | |
| 45 | 1 | 118800698/0 | Ventilation part oil tank | Ventilation part oil tank | |
| 46 | 1 | 118800731/0 | Kåpa | Cover | |
| 47 | 1 | 2653090 | Skruv | Screw | |
| 48 | 1 | 118800719/0 | Stift | Plug | |
| 49 | 1 | 118800653/0 | Felt | Felt | |
| 50 | 1 | 118800672/0 | Handskydd | Buffer | |





SP 36 - Model Year 2012

| Pos. Fig. | Antal Quantity | Art No Part No | Benämning | Description | Anmärkning Notes |
|-----------|----------------|----------------|------------------|--------------------------------|------------------|
| 1 | 1 | 118800650/0 | Circlip | Circlip | |
| 2 | 1 | 118800640/0 | Bricka | Washer | |
| 3 | 1 | 118800710/0 | Bricka | Washer | |
| 4 | 1 | 118800703/0 | Koppling kpl | Centrifugal clutch | |
| 5 | 1 | 118800642/0 | Bricka | Washer | |
| 6 | 1 | 118800704/0 | Kopplingshjul | Clutch drum | |
| 7 | 1 | 118800732/0 | Bromsband | Brake band | |
| 8 | 1 | 118800641/0 | Bricka | Washer | |
| 9 | 1 | 3351010 | Bricka | Safety washer | |
| 10 | 1 | 118800660/0 | Fjäder | Spring | |
| 11 | 1 | 118800706/0 | Adjuster | Adjuster | |
| 12 | 1 | 118800733/0 | Plåt | Pressure plate | |
| 13 | 1 | 118800661/0 | Fjäder | Pressure spring | |
| 14 | 1 | 118800724/0 | Kåpa | Brake band cover | |
| 15 | 3 | 2123100 | Skruv | Screw | |
| 16 | 1 | 118800673/0 | Oil Pump set | Oil pump set | |
| 17 | 1 | 118800722/0 | Activator | Activator | |
| 18 | 1 | 2123100 | Skruv | Screw | |
| 19 | 1 | 118800714/0 | Oil hose | Oil hose | |
| 20 | 4 | 118800663/0 | Bricka | Washer | |
| 21 | 4 | 2135120 | Skruv | Screw | |
| 22 | 1 | 118800688/0 | Vevaxel | Crankshaft | |
| 23 | 2 | 118800686/0 | Axelhylsa | Sleeve | |
| 24 | 2 | 118800649/0 | Tätningring | Oil seal | |
| 25 | 1 | 118801068/0 | Cylinder + Kolv | Cylinder + piston | |
| 26 | 1 | 118801069/0 | Kolv | Piston | |
| 27 | 1 | 118800680/0 | Låsring | Piston ring | |
| 28 | 2 | 118800651/0 | Låsring | Ring | |
| 29 | 1 | 118800674/0 | Kolvbult | Piston pin | |
| 30 | 2 | 118800684/0 | Packning | Gasket | |
| 31 | 1 | 118800627/0 | Skruv | Screw | |
| 32 | 1 | 118800652/0 | Bricka | Toothed washer | |
| 33 | 1 | 118800693/0 | Svänghjul | Fan wheel | |
| 34 | 1 | 118800664/0 | Bricka | Washer | |
| 35 | 1 | 118800637/0 | Mutter | Nut | |
| 36 | 1 | 118800648/0 | Kompass | Needle sleeve | |
| 37 | 1 | 118800692/0 | Elektronikspole | Ignition module | |
| 38 | 1 | 3657050 | Tändstiftsfjäder | Contact spring | |
| 39 | 1 | 118800670/0 | Tändstiftshatt | Spark plug cap | |
| 40 | 3 | 2312120 | Bricka | Tension spring | |
| 41 | 2 | 118800628/0 | Skruv | Screw | |
| 42 | 1 | 118800671/0 | Jordkabel | "Cable; ground + shortcircuit" | |
| 43 | 1 | 118800669/0 | Brytarm | Short circuit switch | |
| 44 | 2 | 118800662/0 | Spring ring | Spring ring | |
| 45 | 1 | 118800690/0 | Insugningsrör | Manifold | |
| 46 | 1 | 118800694/0 | Ljuddämpare | Exhaust | |
| 47 | 1 | 118800676/0 | Basplatta | Isolation plate | |
| 48 | 1 | 118800682/0 | Packning | Exhaust gasket | |
| 49 | 2 | 118800634/0 | Skruv | Screw | |
| 50 | 2 | 2432040 | Mutter | Nut | |
| 51 | 6 | 2330020 | Bricka | Tension washer | |
| 52 | 1 | 118800691/0 | Förgasare | Carburetor | |
| 53 | 1 | 118800725/0 | Filter housing | Filter housing | |
| 54 | 1 | 118800681/0 | Filter plate | Filter plate | |
| 55 | 1 | 118800679/0 | Filter plate | Filter plate | |
| 57 | 2 | 118800636/0 | Skruv | Screw | |
| 58 | 1 | 118800632/0 | Skruv | Screw | |
| 59 | 1 | 118800701/0 | Primer | Primer | |
| 60 | 1 | 118800659/0 | Primerslang | Hose | |





SP 36 - Model Year 2012

| Pos. Fig. | Antal Quantity | Art No Part No | Benämning | Description | Anmärkning Notes |
|-----------|----------------|----------------|-------------------|-------------------|------------------|
| 61 | 1 | 118800720/0 | Chokearm | Choke lever | |
| 62 | 1 | 118800721/0 | Stift | Pin | |
| 63 | 1 | 118800675/0 | Throttle linkage | Throttle linkage | |
| 64 | 2 | 118800632/0 | Skruv | Screw | |
| 65 | 2 | 118800667/0 | Gummihylsa | Grommet | |
| 66 | 1 | 118800683/0 | Carburetor gasket | Carburetor gasket | |
| 67 | 1 | 118800716/0 | Stötfångare | Hand protection | |
| 68 | 1 | 118800647/0 | Axelhylsa | Sleeve | |
| 69 | 1 | 118800663/0 | Bricka | Washer | |
| 70 | 1 | 2312280 | Bricka | Washer | |
| 71 | 1 | 118800631/0 | Skruv | Screw | |
| 72 | 1 | 118800709/0 | Skruv | Screw | |
| 73 | 1 | 12150000/0 | Mutter | Nut | |
| 74 | 1 | 118800668/0 | Fjäder | Torsion spring | |
| 75 | 1 | 3210385 | Tändstift | Spark plug | |