



Genuine Spare Parts




Joist
Spareparts
Joist



Utgåva Issue		Bildnr Picture No		SP 460- SP 510 KÅPOR		SP 460- SP 510 HOUSING		Sida Page	
2004- 12		1365A						336	
Pos. Fig.	Antal/Quantity		Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes		
	4115	4116							
1	1	1	1911-3571-01	Handtag.....	Handle.....				
2	10	10	1911-3015-01	Bricka.....	Washer.....				
3	4	4	1911-3001-01	Skruv.....	Screw.....				
4	5	5	1911-3457-01	Stötdämpare.....	Shock absorber.....				
5	5	5	1911-3393-01	Bussning.....	Bushing.....				
6	7	7	1911-3006-01	Skruv.....	Screw.....				
7	5	5	1911-3476-01	Propp.....	Cap.....				
9	9	9	1911-3007-01	Skruv.....	Screw.....				
10	1	1	1911-3551-01	Start kpl.....	Starter assy.....		Inkl. 11- 19, 51- 54		
11	4	4	1911-3277-01	• Bussning.....	• Bushing.....				
12	1	1	1911-3472-01	• Starthandtag.....	• Starter handle.....				
13	1	1	1911-3176-01	• Startfjäder.....	• Starter spring.....				
14	1	1	1911-3371-01	• Bussning.....	• Bushing.....				
15	1	1	1911-3096-01	• Skiva.....	• Disc.....				
16	1	1	1911-3572-01	• Linhjul.....	• Starter pulley.....				
17	1	1	1911-3129-01	• Startsnöre.....	• Starter cord.....				
18	1	1	1911-3071-01	• Bricka.....	• Washer.....				
19	1	1	1911-3001-01	• Skruv.....	• Screw.....				
20	1	1	1911-3582-01	Kabel m.hölje.....	Cable w.sheath.....				
21	1	1	1911-3053-01	Stoppkontakt.....	Stop switch.....				
22	1	1	1911-3588-01	Handtag kpl.....	Handle assy.....		Inkl. pos 23 - 39		
23	1	1	1911-3524-01	• Bensintanklock kpl.....	• Fuel cap assy.....		Inkl. pos 24		
24	1	1	1911-3430-01	• O- ring.....	• O- ring.....				
25	1	1	1911-3525-01	• Oljetanklock kpl.....	• Oil tank cap assy.....		Inkl. pos 26		
26	1	1	1911-3432-01	• O- ring.....	• O- ring.....				
27	1	1	1911-3492-01	• Lock.....	• Cap.....				
28	1	1	1911-3558-01	• Bränslerör.....	• Fuel tube.....				
32	1	1	1911-3561-01	• Oljerör.....	• Oil tube.....				
33	1	1	1911-3620-01	• Oljefilter.....	• Oil filter.....				
34	1	1	1911-3619-01	• Bränslefilter.....	• Fuel intake filter.....				
35	1	1	1911-3419-01	• Gasreglageänk.....	• Throttle link.....				
36	1	1	1911-3408-01	• Fjäder.....	• Spring.....				
37	2	2	1911-3325-01	• Fjäderpinne.....	• Spring pin.....				
38	1	1	1911-3449-01	• Gasreglage.....	• Throttle lever.....				
39	1	1	1911-3450-01	• Säkerhetsspärr.....	• Safety lever.....				
40	1	1	1911-3327-01	Slangklämma.....	Clamp.....				
41	4	4	1911-3278-01	Mutter.....	Nut.....				
42	1	1	1911-3498-01	Luftfilter.....	Air filter.....				
43	2	2	1911-3287-01	Skruv.....	Screw.....				
44	1	1	1911-3604-01	Luftfilterkåpa.....	Air filter cover.....				
45	1	1	1911-3249-01	• Skruv.....	• Screw.....				
46	1	1	1911-3350-01	• Svärdplåt.....	• Bar plate.....				
47	1	1	1911-3553-01	Kopplingshus kpl.....	Clutch housing assy.....		Inkl. pos 45, 46		
48	2	2	1911-3030-01	Mutter.....	Nut.....				
49	1	1	1911-3227-01	Svärd.....	Bar.....		13" (0.325"x0.058)		
49	1	1	1911-3228-01	Svärd.....	Bar.....		16" (0.325"x0.058)		
49	1	1	1911-3229-01	Svärd.....	Bar.....		18" (0.325"x0.058)		
X 50	1	1	1519-9003-56	Kedja (56E).....	Chain (56E).....		21BP (0.325")		
X 50	1	1	1519-9003-66	Kedja (66E).....	Chain (66E).....		21BP (0.325")		
X 50	1	1	1519-9003-72	Kedja (72E).....	Chain (72E).....		21BP (0.325")		
51	2	2	1911-3480-01	• Startspärr.....	• Starter hook.....				
52	1	1	1911-3481-01	• Hållare- startspärr.....	• Guide- starter hook.....				
53	1	1	1911-3413-01	• Fjäder.....	• Spring.....				
54	1	1	1911-3397-01	• Bussning.....	• Bushing.....				
55	1	1	1911-3519-01	Kedjeskydd.....	Chain cover.....		13"		
55	1	1	1911-3520-01	Kedjeskydd.....	Chain cover.....		16 - 18"		
56	1	1	1911-3557-01	Tbh- påse.....	Accessory bag.....				




Utgåva Issue		Bildnr Picture No		SP 460- SP 510 MOTOR		SP 460- SP 510 ENGINE		Sida Page	
2004- 12		1366A						338	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4115	4116							
1	6	6		1911-3006-01	Skruv	Screw			
2	1	1		1911-3510-01	Ljuddämpare	Muffler			
3	1	1		1911-3370-01	• Ljuddämparpackning	• Muffler gasket			
4	4	4		1911-3022-01	Mutter	Nut			
5	4	4		1911-3009-01	Skruv	Screw			
6		1		1911-3196-01	Cylinder kpl m.kolv	Cylinder assy w.pist.		Inkl. pos 7	
6	1			1911-3596-01	Cylinder kpl m.kolv	Cylinder assy w.pist.		Inkl. pos 7	
7		1		1911-3195-01	• Kolv kpl	• Piston assy		Inkl. pos 8 - 10	
7	1			1911-3595-01	• Kolv kpl	• Piston assy		Inkl. pos 8 - 10	
8		1		1911-3046-01	•• Kolvring	•• Piston ring			
8	1			1911-3303-01	•• Kolvring	•• Piston ring			
9		1		1911-3050-01	•• Kolvbult	•• Piston pin			
9	1			1911-3305-01	•• Kolvbult	•• Piston pin			
10	2	2		1911-3068-01	•• Låsring	•• Lock ring			
11	1	1		1911-3300-01	• Nällager	• Needle bearing			
12	1	1		1911-3586-01	Vevaxel kpl	Crankshaft assy		Inkl. pos 11	
13	1	1		1911-3048-01	Svänghjulskey	Flywheel key			
15	1	1		1911-3441-01	• Cylinderpackning	• Cylinder gasket			
16	1	1		1911-3580-01	Handskydd	Hand guard			
17	1	1		1911-3523-01	Kedjelänk	Chain connection			
18	1	1		1911-3379-01	Pinnbult	Pin			
19	1	1		1911-3092-01	Klämma	Clamp			
20	1	1		1911-3421-01	Fjäder	Spring			
21	2	2		1911-3116-01	Gummihylsa	Grommet			
22	1	1		1911-3470-01	Tändstiftshatt	Spark plug cover			
23	1	1		1911-3433-01	Gummibricka	Rubber washer			
24	1	1		9400-0258-00	Tändstift	Spark plug		Champion CJ7Y	
25	1	1		1911-3055-01	• Tändstiftskabel	• Spark plug cable			
26	1	1		1911-3313-01	Elektronikspole	Electronic coil			
27	1	1		1911-3568-01	Svänghjul	Flywheel			
31	1	1		1911-3268-01	Bricka	Washer			
32	1	1		1911-3280-01	Mutter	Nut			
33	5	5		1911-3476-01	Propp	Cap			
34	8	8		1911-3001-01	Skruv	Screw			
35	5	5		1911-3393-01	Bussning	Bushing			
36	5	5		1911-3457-01	Stötdämpare	Shock absorber			
37	4	4		1911-3010-01	Skruv	Screw			
38	2	2		1911-3259-01	Skruv	Screw			
39	2	2		1911-3272-01	Bricka	Washer			
40	1	1		1911-3592-01	Vevhus kpl	Crankcase assy		Inkl. 41,118,119,121	
41	2	2		1911-3240-01	• Svärdskruv	• Bar screw			
43	1	1		1911-3044-01	Tätningring	Seal ring			
44	1	1		1911-3043-01	Tätningring	Seal ring			
45	2	2		1911-3297-01	Kullager	Ball bearing			
46	1	1		1911-3347-01	Bromsband	Brake band			
47	1	1		1911-3587-01	Oljepump kpl	Oil pump assy		Inkl. pos 50	
48	1	1		1911-3459-01	Packning	Gasket			
49	1	1		1911-3348-01	Kopplingskiva	Clutch disc			
50	1	1		1911-3308-01	• Skruvhylsa	• Female screw			
51	1	1		1911-3552-01	Koppling	Clutch			
52	1	1		1911-3511-01	Kedjedrev	Sprocket			
53	1	1		1911-3298-01	Nällager	Needle bearing			
54	1	1		1911-3338-01	Drevbricka	Sprocket washer			
55	1	1		1911-3330-01	Låsring	Circlip			
56	1	1		1911-3512-01	Kedjebromsarm	Chain brake lever			
57	1	1		1911-3409-01	Fjäder	Spring			
58	1	1		1911-3380-01	Pinnbult	Pin			
59	1	1		1911-3530-01	Kedjesträckare	Chain tensioner			
60	1	1		1911-3349-01	Svärdplåt	Bar plate			
61	1	1		1911-3005-01	Skruv	Screw			
62	1	1		1911-3458-01	Insugningsrör	Intake manifold			
63	1	1		1911-3531-01	Fläns	Flange			
64	10	10		1911-3015-01	Bricka	Washer			



Utgåva Issue		Bildnr Picture No		SP 460- SP 510 MOTOR		SP 460- SP 510 ENGINE		Sida Page	
2004- 12		1366A						340	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4115	4116							
65	1	1		1911-3565-01	Förgasrstöd	Carburettor support			
66	9	9		1911-3007-01	Skruv	Screw			
67	1	1		1911-3351-01	Bussning	Bushing			
68	2	2		1911-3422-01	Slangklämma	Clamp			
69	1	1		1911-3503-01	Slang	Carb. pulse pipe			
71	1	1		1911-3497-01	Luftfilterstöd	Air filter support			
72	1	1		1911-3489-01	Luftfilterhållare	Air filter holder			
73	1	1		1911-3465-01	Gummihylsa	Grommet			
74	1	1		1911-3451-01	Chokereglage	Choke lever			
75	2	2		1911-3262-01	Skruv	Screw			
76	1	1		1911-3559-01	Förgasare kpl	Carburettor assy			
109	1	1		1911-3614-01	Packningssats	Gasket set		Walbro WT429 Inkl. pos 3, 15	
116	1	1		1911-3257-01	Skruv	Screw			
117	1	1		1911-3016-01	Bricka	Washer			
118	1	1		1911-3471-01	• Kedjestopp	• Chain stop			
119	1	1		1911-3008-01	• Skruv	• Screw			
120	1	1		1911-3022-01	Mutter	Nut			
121	1	1		1911-3260-01	• Skruv	• Screw			
122	1	1		1911-3362-01	Spikjärn	Spike			
123	1	1		1911-3276-01	Bricka	Washer			
124	1	1		1911-3537-01	Dekompression	Decompression			

76



Utgåva Issue		Bildnr Picture No		SP 460- SP 510 FÖRGASARE WALBRO WT429		SP 460- SP 510 CARBURETTOR WALBRO WT429		Sida Page	
2004- 12		1367A						342	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4115	4116							
76	1	1		1911-3559-01	Förgasare kpl.....	Carburettor assy			
77	1	1		1911-3285-01	• Skruv	• Screw			
78	1	1		1911-3425-01	• Lock.....	• Cover.....			
79	1	1		1911-3407-01	• Fjäder.....	• Spring			
80	1	1		1911-3291-01	• Tomgångsskruv	• Idle speed screw			
83	1	1		1911-3495-01	• Nät.....	• Screen.....			
84	1	1		1911-3467-01	• Nippel	• Fitting.....			
85	4	4		1911-3284-01	• Skruv	• Screw			
86	1	1		1911-3286-01	• Skruv	• Screw			
87	1	1		1911-3410-01	• Fjäder.....	• Spring			
88	3	3		1911-3283-01	• Skruv	• Screw			
89	1	1		1911-3345-01	• Gasspjäll.....	• Throttle shutter			
90	1	1		1911-3395-01	• Gasspjällaxel.....	• Throttle shaft			
91	1	1		1911-3352-01	• Chokespjäll	• Choke shutter			
92	1	1		1911-3396-01	• Chokespjällaxel.....	• Choke shaft			
93	1	1		1911-3496-01	• Filter	• Filter.....			
94	1	1		1911-3332-01	• Hållare	• Retainer.....			
95	1	1		1911-3289-01	• Justerskruv- min.....	• Mixture screw- idle.....			
96	1	1		1911-3404-01	• Fjäder.....	• Spring			
97	1	1		1911-3293-01	• Justerskruv- max	• Mixture screw- high			
98	1	1		1911-3405-01	• Fjäder.....	• Spring			
99	1	1		1911-3344-01	• Plugg	• Plug.....			
100	1	1		1911-3343-01	• Plugg	• Welch plug			
101	1	1		1911-3381-01	• Nålventil.....	• Inlet needle.....			
102	1	1		1911-3384-01	• Sprint.....	• Pin.....			
103	1	1		1911-3406-01	• Fjäder.....	• Spring			
104	1	1		1911-3337-01	• Ventilarm	• Control lever.....			
107	1	1		1911-3333-01	• Lock.....	• Cover.....			
108	1	1		1911-3612-01	• Membran- packningsatts...	• Diaphragm- gasket set			
110	1	1		1911-3394-01	• Bussning.....	• Bushing.....			
111	1	1		1911-3359-01	• Arm.....	• Lever.....			
112	1	1		1911-3412-01	• Fjäder.....	• Spring			
113	1	1		1911-3360-01	• Arm.....	• Lever.....			
114	1	1		1911-3478-01	• Bussning.....	• Bushing.....			
115	1	1		1911-3294-01	• Skruv	• Screw			